## Recessed LED Downlight


EN Read this instruction carefully before commencing installation and keep it for future reference. Always switch off the mains before installation or maintenance. Keep the product far from heat sources and in a well ventilated area. The installation or maintenance should be carried out by a gualified electrician.

The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.



A

26mm



-Ø30mm



CORE 12° 38°

CORE 120°

Surface mount ring for12° and 38°

Surface mount ring for100°



